




4-tier Construction



Fixtures included in this pack: -



This pack contains the parts for both 4 and 5-tier versions of the stand, therefore not all the fixtures supplied will be used.

ASSEMBLY INSTRUCTIONS

1. Place the top board (A) upside down on the floor (the ribbed underside should be facing up).
2. Screw short spacers (B) onto the four threaded rods in the corners of the board.
3. Place the first of the two shelves over the threaded ends of the short spacers, ensuring that the ribbed underside of the shelf is facing up.
4. Attach additional short spacers (E) to the threads of the first set which are protruding through the first shelf.
5. Place the second shelf over the ends of the spacers, once again making sure the ribbed underside is facing up.
6. Attach the long spacers (D) to the ends of the protruding threads on the second shelf.
7. Complete the unit by placing the base board over the ends of the long spacers and attaching the legs (F) where indicated by the orange stickers.
8. Attach end caps (G) to the base where indicated by green stickers and use a coin to tighten.
9. Now the stand may be turned the right way up.
10. Insert the Cable Tidy Boards (H) into the slots provided.

POSITIONING AND LEVELLING THE UNIT

1. The unit should first be positioned in the location it is to be used. If it is placed on a carpeted surface then it would be necessary to press down firmly, ensuring that the spikes have penetrated fully.
2. Make sure the spikes are fully tightened. If the unit is rocking then extend the appropriate legs by unscrewing until the unit no longer rocks.
3. Now place a spirit level from front to back and extend one of the front/back legs until the indicator in the level moves to the centre.
4. Rotate the level through 90 degrees and raise either the left or right leg until the level indicator is central.

Your stand should now be ready to use.